



# LightTro

## user guide

Color Kinetics Incorporated  
10 Milk Street, Suite 1100  
Boston, MA 02108  
Tel 617 423 9999  
www.cksauce.com



©2002-2003 Color Kinetics Incorporated.  
All rights reserved. Color Kinetics is a registered trademark and Sauce and the Sauce logo are trademarks of Color Kinetics Incorporated. Product designed in the USA. Made and assembled in China. US Patents 6,150,774. Other Patents Pending  
PUB-000078-01R00

### Included in this package

- One LightTro Bulb
- User Guide

### Additional items needed

- A standard light fixture: lamp, sconce, chandelier, etc.

**NOTE:** This product can be used on a dimmer circuit. However, when used with a dimmer the bulb will not dim but will turn OFF. It is recommended to set the dimmer circuit at full brightness.

## CAUTION

- THIS DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY FIXTURES OR EMERGENCY EXIT LIGHTS.
- USE ONLY WITH UL LISTED LIGHT FIXTURES.

## WARNING

- THIS IS NOT A TOY AND IS NOT INTENDED FOR USE BY CHILDREN.
- ADULT USE AND INSTALLATION ONLY
- RISK OF ELECTRIC SHOCK - USE IN DRY LOCATIONS ONLY.
- THIS PRODUCT HAS NO USER SERVICEABLE PARTS. DO NOT OPEN LIGHT, RISK OF ELECTRIC SHOCK AND DEATH BY ELECTROCUTION EXISTS!

### SPECIFICATION

- 100-120VAC, 2W, 50/60Hz, 0.05A

LIMITED WARRANTY – THIS PRODUCT WILL BE FREE FROM MATERIAL DEFECTS IN MATERIALS AND WORKMANSHIP FOR 90 DAYS FROM PURCHASE. THIS WARRANTY DOES NOT COVER DAMAGE CAUSED BY ACCIDENT, MISUSE OR ABUSE. ANY IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED TO THE SAME 90 DAY PERIOD. SOME STATES RESTRICT LIMITATIONS ON IMPLIED WARRANTIES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY EXCLUDES PUNITIVE, SPECIAL, CONSEQUENTIAL AND INCIDENTAL DAMAGES. SOME STATES RESTRICT LIMITATIONS OF REMEDIES, SUCH AS FOR PERSONAL INJURIES, SO THE ABOVE LIMITATION MAY NOT APPLY. THE SOLE REMEDY FOR ANY DEFECT SHALL BE THE REPAIR OR REPLACEMENT OF THE PRODUCT. SHIP YOUR LIGHTTRO AND A COPY OF YOUR PURCHASE RECEIPT ALONG WITH YOUR RETURN ADDRESS AND AN EXPLANATION OF THE REASON FOR RETURN, POSTAGE PREPAID, TO COLOR KINETICS INCORPORATED 10 MILK STREET SUITE 1100 BOSTON, MA 02108, ATTENTION: CUSTOMER RETURNS DEPARTMENT. THIS WARRANTY GIVES SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

## Introduction

LightTro from Sauce™ is the first screw-in color changing light of its kind. LightTro fits standard light fixtures and features pre-programmed digital color lighting effects. The easy-to-use control makes setting shows a snap.

## Mode Descriptions

**COLOR WASH** - a smooth transition through the color spectrum.

**FIXED COLORS** - a static display of any one color.

**WATER EFFECT** - a soothing transition from blue to green to mimic the changing tides.


**SUNSET EFFECT** - an illusion of a warm, red to orange, sunset.

**ECLIPSE EFFECT** - a gentle blue to magenta wash.

**RANDOM COLOR** - a random display of colors stepping from one color to the next.

## LightTro Models

LightTro comes in three models with push button control.



**Bulb:** The ideal choice for lamps with snap-on shades.

**PAR:** Perfect for recessed or track lighting

**Twist:** Great direct-view lighting for chandeliers and sconces.

## Before you install

- Read the User Guide to ensure that you get the maximum effects and enjoyment from your LightTro. Pay close attention to cautions and warnings.
- If you are installing LightTro into a chandelier or limited access light fixture, use a lamp or easily accessible fixture as a test fixture to view, adjust, and select your desired effect. Once you have selected an effect, remove LightTro from the test fixture and place it into the desired fixture. LightTro's on-board memory remembers the last show selected when it is installed into its new location.

## Push Button Control

LightTro with push button control offers six color changing effect modes.

- Press and release to cycle through the modes: Color Wash, Fixed Colors, Water, Sunset, Eclipse, and Collage.
- Press and hold to modify each mode. The blink indicates transition to the next sub-mode.

MODE	PRESS AND HOLD ACTION
COLOR WASH	sets cycle time: fast, medium, slow.
FIXED COLORS	selects a color.
WATER EFFECT	sets cycle time: fast, slow.
SUNSET EFFECT	sets cycle time: fast, slow.
ECLIPSE EFFECT	sets cycle time: fast, slow.
RANDOM COLOR	sets cycle time: fast, slow, and select white strobe.